



5455-2

UNIVERSAL BOLT HOLDER

- Used for replacing pins on clevis type hardware
- Jaw is spring loaded

CAT NO	DESCRIPTION	LBS
5455-2	UNIVERSAL BOLT HOLDER	1.5



5455-15

UNIVERSAL LOCATING PIN

- Used to align joints and holes on clevis type suspension insulators and hardware

CAT NO	DESCRIPTION	LBS
5455-15	UNIVERSAL LOCATING PIN	0.5



5454-2

UNIVERSAL BALL SOCKET FORK

- Used to align and hold ball socket fittings for removal of cotter pin

CAT NO	DESCRIPTION	LBS
5454-2	UNIVERSAL BALL SOCKET FORK	0.6



5455-29

UNIVERSAL BALL SOCKET ADJUSTER

- Used to support and align ball socket adapter between ball fitting on disc insulator and clevis fitting on suspension or strain clamp

CAT NO	DESCRIPTION	LBS
5455-29	UNIVERSAL BALL SOCKET ADJUSTER	0.9




5454-6

UNIVERSAL 90 DEGREE ADAPTER

- When mounted on universal sticks, this adapter will allow fittings to be set at almost any angle

CAT NO	DESCRIPTION	LBS
5454-6	UNIVERSAL 90 DEGREE ADAPTER	0.4



5454-5

UNIVERSAL CRESCENT SKINNING KNIFE

- Used to skin conductors before installing hot line clamps and connections
- Replaceable blades

CAT NO	DESCRIPTION	LBS
5454-5	UNIVERSAL CRESCENT SKINNING KNIFE	1.0
1-08402	REPLACEMENT BLADE	0.1