

FIBERGLASS EXTENSION ARM

- The Fiberglass Extension Arm is designed for use as a temporary aid in replacing existing conductors and insulators, or as an aid for moving out conductors to obtain working clearance in congested areas
- Easy to install conductor holders are adjustable
- Eye bolts are silicon bronze to prevent seizing
- Load limit 150 lbs. per conductor holder
- Rating 15KV without insulator and 34.5KV with insulator



5006

2 1/2" DIAMETER FIBERGLASS EXTENSION ARM FOR DISTRIBUTION CROSS ARMS FITS MAXIMUM CROSS ARM SIZE 4 1/4" W x 6 3/4" H			2 1/2" DIAMETER FIBERGLASS EXTENSION ARM FOR SUB TRANSMISSION ARMS FITS MAXIMUM CROSS ARM SIZE 5 1/4" W x 6" H		
CAT NO	DESCRIPTION	LBS	CAT NO	DESCRIPTION	LBS
5000	5' ARM WITH ONE CONDUCTOR HOLDER	11.3	5036	5' ARM WITH ONE CONDUCTOR HOLDER	12.0
5001	5' ARM WITH ONE CONDUCTOR HOLDER AND INSULATOR	11.5	5037	5' ARM WITH ONE CONDUCTOR HOLDER AND INSULATOR	12.3
5006	6' ARM WITH TWO CONDUCTOR HOLDERS	14.5	5016	6' ARM WITH TWO CONDUCTOR HOLDERS	14.5
5007	6' ARM WITH TWO CONDUCTOR HOLDERS AND INSULATORS	15.5	5016-1	6' ARM WITH TWO CONDUCTOR HOLDERS AND INSULATORS	15.5



A10001



A10002



A30008



A10038



A10039

EXTENSION ARM ACCESSORIES FOR ALL 2 1/2" O.D. ARMS

CAT NO	DESCRIPTION	LBS
A10001	CONDUCTOR HOLDER ONLY	2.3
A10002	CONDUCTOR HOLDER AND INSULATOR	2.5
A30008	INSULATOR FOR USE WITH A10001 AND A10038 CONDUCTOR HOLDERS	1.0
A10038	LARGE CONDUCTOR HOLDER HAS 2 5/8" OPENING	2.8
A10039	LARGE CONDUCTOR HOLDER AND INSULATOR	3.8
P10024	EYE SCREW REPLACEMENT	