

INTERNAL ROD SHOTGUN STICK REPAIR PARTS LIST

MODEL	8204	8206	8208	8210	8212
NO DESCRIPTION	CAT NO	CAT NO	CAT NO	CAT NO	CAT NO
1 BASE CAP	P18020	P18020	P18020	P18020	P18020
2 HANDLE	P18545	P18545	P18545	P18545	P18545
3 LEVER ACTUATING SPRING	P13007	P13007	P13007	P13007	P13007
4 LEVER	P10002	P10002	P10002	P10002	P10002
5 1/8 X 3/4 ROLL PIN	P16502	P16502	P16502	P16502	P16502
6 10-32 X 7/8 NUT & BOLT	A16000	A16000	A16000	A16000	A16000
7 TRIGGER	P10003	P10003	P10003	P10003	P10003
8 COMPRESSION SPRING	P13008	P13008	P13008	P13008	P13008
9 10-32 FLAT HEAD SCREW	P16019	P16019	P16019	P16019	P16019
10 PROTECTIVE SLEEVE	SEE PAGE 915	SEE PAGE 915	SEE PAGE 915	SEE PAGE 915	SEE PAGE 915
11 SLIDE STOP	P10005	P10005	P10005	P10005	P10005
12 FRP PIN - (REQUIRES 2)	P15546	P15546	P15546	P15546	P15546
13 INSULATED HEAD	P31467	P31467	P31467	P31467	P31467
14 HOOK ACTUATING SPRING	P13001	P13001	P13001	P13001	P13001
15 SIDE BREAK HOOK GUIDE	P10007	P10007	P10007	P10007	P10007
16 1/4 X 15/32 ROLL PIN	P16528	P16528	P16528	P16528	P16528
17 HOOK JAW SIDE BREAK	P10008	P10008	P10008	P10008	P10008
18 SLOT SLEEVE	P31306	P31306	P31306	P31306	P31306
19 ROD TO HANDLE ADAPTER	P10080	P10080	P10080	P10080	P10080

REPLACEMENT ASSEMBLIES PARTS LIST

A HANDLE ASSEMBLY	A18571	A18571	A18571	A18571	A18571
B FIBERGLASS POLE ASSEMBLY	A20000	A20001	A20002	A20003	A20004
C SIDE BREAK HOOK ASSEMBLY	A10008	A10008	A10008	A10008	A10008
D OPERATING ROD ASSEMBLY	A15612	A15613	A15614	A15615	A15616
E BOTTOM BREAK HOOK ASSEMBLY	A10409	A10409	A10409	A10409	A10409

SHOTGUN STICK REPAIR PARTS LIST - FOR STICKS PRIOR TO JULY 2014

13 INSULATED HEAD	P30195	P30195	P30195	P30195	P30195
15 SIDE BREAK HOOK GUIDE	P10007	P10007	P10007	P10007	P10007
C SIDE BREAK HOOK ASSEMBLY	A10008	A10008	A10008	A10008	A10008
D OPERATING ROD ASSEMBLY	A15524	A15525	A15526	A15527	A15528